

VIPER-F – Power Mortuary Stretcher with Loading System



PRODUCT INFO

Product Nr:	F1030
Length:	160-200 cm
Width:	60 cm (57cm)
Height:	38-133cm
Weight:	75 kg (66kg)
Max Load:	320kg (400 kg)

VIPER-F



The VIPER-F is a high-performance electric mortuary stretcher designed for modern, professional funeral services. With a load capacity of 320 kg and a lifting height up to 90 cm, it offers ergonomic, intuitive operation and exceptional maneuverability.

The VIPER-F includes a wide lift-off Stretcher Model 11BS with adapters to also carry a coffin. One product that handles both transports of bodies on a lift-off stretchers or in a 'coffin'.

Key Features:

- Electrohydraulic lifting system – smooth raising and lowering at the push of a button.
- Ergonomic and user-friendly – intuitive +/- controls and soft-start/stop function.
- Durable and easy to maneuver – aluminum frame with 150 mm swivel wheels and full rubber soft tires.
- Automatic loading system – vehicle integration allows effortless loading/unloading, even on uneven surfaces.
- Crash-tested vehicle mount included – with telescopic guides and auto-lock for secure fixation.
- Integrated tablet/smartphone connectivity for setting height parameters and monitoring system status.
- Onboard battery system – automatically recharges when docked in the vehicle.

The VIPER-F Includes:

- Adapter V 161 S – Multi-Function Coffin & Stretcher Adapter
 - Secure stretcher lock – prevents vertical lifting during transport.
 - Dual mode operation:
 - With brackets folded down: transports FERNO heavy-duty stretcher 11 BS.
 - With brackets upright: securely holds a coffin.
 - Quick-mount system – easily attaches to the frame and locks into place.
 - End-stop plate (M 3369) – adds extra safety during stretcher transport.
- Vehicle Loading System (Standard Equipment)
 - Easy and smooth insertion/removal with ball-bearing telescopic guides.
 - Mechanical centering allows angled entry.
 - Manual override system for loading/unloading without power.
 - Battery charging starts automatically when docked.
- 11BS Lift-Off Stretcher
 - 10 cm wider than regular transfer stretchers
 - Extra lightweight yet loadable up to 250 kg
 - Designed specifically for the transport of very heavy individuals